

## **Installation instructions**

C-Channels may be installed onto the sub-floors by nailing, stapling, gluing or by using a high-strength double-sided tape.

It is recommended that corners are cut using a mitre box and that any joins be positioned out of traffic areas where possible.

Safety statement: When cutting or drilling aluminium we recommend the use of safety glasses and gloves.

